

CHILD CARRIER INSTRUCTIONS



IMPORTANT! READ CAREFULLY AND KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

This product complies with standard:EN 13209-1:2022 AND ASTM F2549-22

Manufacture: WIPHA importers

Manufacturer's Address: 333 canal St, New Orleans, LA70130, United State.

18 Rue des Bas Rogers, 92800, Puteaux, France.

Location of Production: Nanjing City, Jiangsu Province, China P.C.: 210000.

Phone: 0086 25 84643040

www.wipha.com

WARNING

FALL HAZARD

Your child can slip through leg opening or fall out of product and suffer a serious head injury.
•Always use child retention system and adjust to fit snugly.
•Do not use carrier with a child weighing less than 16lb(7.3kg)or more than 40lb(18kg).
•Do not load more than maximum overall weight:42lb(19kg)(Child+ Cargo).
•Do not use carrier if child cannot sit upright unassisted.
•Do not use carrier with child less than six months old.
•Do not place carrier on counter tops,or other elevated surfaces.
•Your balance may be adversely affected by your movement and that of the child.
•Take care when bending or leaning forward or sideways.
•This carrier is not suitable for use during sporting activities and cycling.
•Never leave the child unattended in this framed backpack carrier.
•Read all instructions before assembling and using the child carrier.
•Keep instructions for future use.
•Check to assure all buckles, snaps, straps, and adjustments are secure before each use.
•The instructions for the regular inspection and maintenance of the carrier.
•Periodically check that the child's legs have adequate circulation.
•Be aware of fatigue during prolonged use. Take frequent breaks as needed.
•Never bend at waist; bend at knees.
•Items attached to the carrier may change the balance of the product and cause a hazardous, unstable condition.
•This carrier is designed only for use while walking. It should not be used for any sporting activities such as climbing, cycling, skiing, or similar activities.
•Never use a framed backpack carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
•Do not use this product near fire or open flame.
•Care should be taken to avoid hazards in the environment when in use, as the child may sit higher than the height of the caregiver. For example, door frames, low branches of trees, etc.
•Additional or replacement parts should only be obtained from the manufacturer, importer or organization responsible for its sale.
•Care should be taken when you are putting on or removing the framed backpack carrier.
•The child's restraint system in the framed backpack carrier should be securely fastened and adjusted in accordance with the manufacturer's instructions.
•We do not recommend that you lift the loaded carrier by only one handle to put it on your back. It may not be stable enough. When the child is in the carrier, only lift it using both handles together.
•Be aware that the child in the framed backpack carrier may suffer from the effects of weather and temperature before you do.
•When the child is in the framed backpack carrier, the child could be in a position higher than the carer who should therefore be aware of potential hazards.


FEATURES

-There is a mirror inside the right-hand hip fin pocket. This is to aid in seeing your child when the carrier is on your back.
-Inside the left-hand pocket is a pull-out mesh bottle pocket with shock card bottle retainer.
-Inside the main compartment there is a pocket , the volume of about 2 liters. The pocket has heat preservation effect. A separator is attached in the pocket.
-Reflective webbing light loop Self-contained sunshade. Size:290*290*650 Weight:2.8KG
-The Creeper child carrier is designed to safely and comfortably carry a child that can hold their head up independently and is not more than 100cm tall.Do not use carrier with a child weighing less than 16 lb or more than 40 lb.
-The harness and the child's seat and harness need to be adjusted to suit each user to ensure safe and comfortable use.

LOADING AND LIFTING THE CARRIER

Never leave a child in the carrier unattended as the carrier could fall over if on uneven ground or if the child moves.
-Always load your child with the carrier on flat level ground or on a floor. there are two webbing loops on the back side of the carrier.This webbing loop can be used both as a handle and as a pedel. They are designed for this purpose.
-Either loosen the shoulder straps, or unclip one or both of the quick-release shoulder strap buckles. Lift your child into the carrier. Once your child is as is, clip the chest buckle together and tighten the webbing.
-Never leave a child in the carrier unrestrained. Once the child is secure adjust the padded side fin straps so the child is as possible to the back of the wearers harness. This will bring the load closer to your back making the loaded carrier more stable on your back and easier to carry.
-Once the child is loaded and secure and the side straps adjusted lift the carrier onto your back. This can be initially difficult. There are several ways to make it easier: you can lift the loaded carrier onto a higher surface such as bench,table or chair and then turn around and put the carrier onto your back. Another option is to crouch beside the carrier and with one knee on the ground lift the loaded carrier onto your other knee.
-Pivot your torso to get one shoulder(same side as the knee that has the carrier on it) under the shoulder strap. Lean forward so the carrier is on your back and put your other arm under the other shoulder strap.You can now stand and secure the hip belt.If there is someone to help you, the front and rear carry handles can be used to lift the carrier up to a comfortable height with the child sitting in place.
-We do not recommend that you lift the loaded carrier by only one handle to put it on your back. It may not be stable enough. When the child is in the carrier, only lift it using both handles together.
-The shoulder straps should be snug and taking some of the load.
-Be aware that the child in the framed backpack carrier may suffer from the effects of weather and temperature before you do.
-When the child is in the framed backpack carrier, the child could be in a position higher than the carer who should therefore be aware of potential hazards.

ADJUST THE CARRY SYSTEM



The adult harness on the Creeper child carrier is easily adjusted to fit different users. The main adjustment is back length.

-Unfolding the back waist cover. The pad is hinged at the bottom and held in place with Velcro and a stiffened tongue that tucks behind the back panel(Fig 1).
-To shorten the length of the shoulder strap, please tighten the strap A; If you want to increase the length of the shoulder strap, please loosen the strap A and let it fit properly. Then, tighten the strap and place the padding back in its original position. The length of the shoulder strap should be adjusted according to the height of the person carrying it. There is a height size label on the left side of the A strap.
-The perfect position:the shoulder straps' anchor points rest between the shoulder blades.For precise adjustment lower or raise the shoulder straps that make sure the weight is concentrated on the back hip bones.
-Loosen the top stabilizer straps(Fig 2) and shoulder straps, then put the carrier on your back.Do up the hip belt with the top of the belt sitting on the top of your hipbones.Tension the hip belt so it is very snug and comfortable on your hips. Make sure the weight is concentrated on the back hip bones. That is very important.
-Now check the shoulder strap position. The top of your shoulder should be 5cm above where the shoulder straps bend away from the harness back panel(Fig 2).
-Note:It may be easier to do this adjustment the first time wearing the carrier with the lumbar pad hanging open.
-Remark: il peut être plus facile de faire cet ajustement la première fois en portant le support avec le coussin lombaire suspendu ouvert.

ADJUSTING THE CHILD HARNESS

The child seat and harness need to be adjusted as your child grows or if another child uses carrier.

-Height adjustable seat allows the child to always sit in the ideal position: the chin on the level of the upper half of the chin pad.

-Start by adjusting the seat height. Release the seat side straps(Fig 5). Adjust the seat height using the seat height adjustment strap(Fig 5). Pull the strap up through the adjuster buckle to raise the seat. To lower the seat, pull the edge of the adjuster buckle away from the strap to release it. For younger children, the saddle is set at the correct height when your child's is resting against the headrest.

-Two children's foot pedals under the back frame Some parents often complain that children stepping on foot pedals is very annoying. But some parents also believe that using pedals can make their children more comfortable.

-When using a foot pedal, parents need to put their children's feet into the pedal by hand.

Through this method, parents can choose whether to use foot pedals according to their own needs.

Ajustement du système de transport

-The last adjustment is the Sternum Strap(Fig 1). Clip the buckle together and adjust the height of the sternum strap by sliding both sides up or down.

-The sliding buckles that attach the sternum strap to the shoulder straps have a split in them. This enables them to be removed and repositioned in the upper or lower part of the slide webbing to suit the user. The Sternum Strap is properly positioned when the strap crosses your chest just below your collarbones.

-Note: Adjustment while in use may be required to alleviate any soreness. This adjustment sequence will give the optimum carrying comfort.

-The chin pad is made of a heat-insulating aluminum membrane. It has a thermal insulation effect.this insulated pocket for baby'bottle.

-Start by adjusting the seat height. Release the seat side straps(Fig 5). Adjust the seat height using the seat height adjustment strap(Fig 5). Pull the strap up through the adjuster buckle to raise the seat. To lower the seat, pull the edge of the adjuster buckle away from the strap to release it. For younger children, the saddle is set at the correct height when your child's is resting against the headrest.

-Two children's foot pedals under the back frame Some parents often complain that children stepping on foot pedals is very annoying. But some parents also believe that using pedals can make their children more comfortable.

-When using a foot pedal, parents need to put their children's feet into the pedal by hand.

Through this method, parents can choose whether to use foot pedals according to their own needs.

Les sangles adultes sur les porte - enfants creeper peuvent être facilement ajustées pour s'adapter à différents utilisateurs. Le principal ajustement est la longueur du dos.

-Dépliant la couverture de la taille arrière. Le tampon est articulé en bas et maintenu en place avec du velcro et une langue raide qui tire derrière le panneau arrière (Fig 1).

-Pour raccourcir la longueur de la sangle, serrez la sangle a; Si vous souhaitez augmenter la longueur de votre bandoulière. Desserrez la bandoulière à pour la rendre appropriée. Ensuite, serrrez la sangle et remettez le rembourrage en place. La longueur de la bandoulière doit être ajustée en fonction de la hauteur du porteur. Une étiquette de taille de hauteur est disponible sur le côté gauche de la sangle.

-La position parfaite: les points d'ancre des bretelles reposent entre les jambes de l'épaule. Pour un ajustement précis, abaissez ou relevez les bretelles pour vous assurer que le poids est concentré sur les os de la hanche arrière.

-Desserrez les sangles stabilisatrices supérieures (Fig 2) et bretelles d'épaule puis mettez le support sur votre dos. Faites monter la ceinture de hanche avec le haut de la ceinture assis sur le dessus de vos hanches. Tension la ceinture de hanche donc il est très serré et confortable sur vos hanches. Assurez-vous que le poids est concentré sur les os de la hanche arrière. C'est très important.

-Vérifiez la position de la sangle d'épaule. Le haut de votre épaule devrait être à 5cm au-dessus de l'endroit où les bretelles se plient à partir du panneau arrière du harnais (Fig 2).

-Note:Il peut être plus facile de faire cet ajustement la première fois en portant le support avec le coussin lombaire suspendu ouvert.

-Une fois que les bretelles ont été ajustées à un seul utilisateur, marquer la position de la boucle sur l'étiquette imprimée (Fig 1). En marquant la boucle à chaque utilisateur de boucle, le harnais peut être rapidement réajusté pour convenir à chaque personne.

-Now start the final adjustments by tensioning the hip belt. It should be tightened so it is very snug on your hips and cannot move around.

-Note: If it is not tight enough, too much weight will be transferred to the shoulder pads. If it is too tight your circulation may be compromised and/or uncomfortable on your hipbones.

-Height adjustable seat allows the child to always sit in the ideal position: the chin on the level of the upper half of the chin pad.

-Check and tension the hipbelt side adjusters until the carrier feels stable against your hips.

-Once the hip belt is adjusted the shoulder pads can be tensioned; stand up straight and tighten the shoulder straps.

-At this point, fitting the Velcro will bond tightly. The hinges are in a straight line without folding. Make sure the frame is firmly supported.

-The shoulder straps should be snug and taking some of the load.

-Note: If they are too tight the hip fins will rise off your hips. If they are too loose the carrier will not sit against your back.

-Ensure that the cushions are completely dry before storing the carrier as mildew can develop. We recommend the pads are placed in a protective wash bag if going in a machine as the Velcro patches may damage other clothing.

-Once the shoulder straps are adjusted, move the sliding buckle (Fig 2) on the top of the shoulder straps until they are on top of your shoulders. Tension the top stabiliser so the carrier is drawn against your body.

-Les bretelles doivent être serrées et prendre une partie de la charge.

-Remarque: si elles sont trop serrées, les épaulettes peuvent lâcher.

-Clean in warm water with a mild detergent. Do not use bleach.

-Remarque: si elles sont trop serrées, les épaulettes peuvent lâcher.

-The small pocket in the storage compartment has a volume of about 2 liters. The pocket is made of a heat-insulating aluminum membrane. It has a thermal insulation effect.this insulated pocket for baby'bottle.

-Once the shoulder straps are adjusted, move the sliding buckle (Fig 2) on the top of the shoulder straps until they are on top of your shoulders. Tension the top stabiliser so the carrier is drawn against your body.

-Tendez le stabilisateur supérieur pour que le porteur soit tiré contre votre corps.

-Au pli du cadre, aplatissez la charnière pliée vers le bas. Lorsque la charnière est linéaire, le cadre est complètement étendu. Ensuite, vous pouvez mettre dans les articles que vous voulez transporter. Soulevez la charnière droite et le cadre pliera et rangerà. Le cadre est réduit en taille. Une fois le cadre supporté, l'extrémité de la petite boucle noire de la sangle est accrochée à la poignée blanche articulée.

-A ce stade, l'installation de velcro sera étroitement collée. La charnière est en ligne droite, sans pli. Assurez - vous que le support du cadre est solide.

-La petite poche dans le compartiment de stockage a un volume d'environ 2 litres.

-La poche est faite d'une membrane en aluminium isolant la chaleur. Il a un effet d'isolation thermique. Cette poche isotherme pour biberon. Un séparateur y est attaché.

-Une fois les bretelles ajustées, déplacez la boucle coulissante (Fig 1) sur le dessus des bretelles jusqu'à ce qu'elles soient sur le dessus de vos épaules. Tendez le stabilisateur supérieur pour que le porteur soit tiré contre votre corps.

-Tendez le stabilisateur supérieur pour que le porteur soit tiré contre votre corps.

-Le dernier réglage est la sangle du sternum (Fig 1) serrez la boucle ensemble et ajustez la hauteur de la sangle du sternum en glissant des deux côtés vers le haut ou vers le bas.

-Les boucles coulissantes qui fixent la sangle du sternum aux bretelles ont une fente en elles. Cela permet de les enlever et de les repositionner dans la partie supérieure ou inférieure de la sangle de glissement pour convenir à l'utilisateur. La sangle du sternum est correctement positionnée lorsque la sangle croise votre poitrine juste en dessous de vos clavicules.

-Remarque: un ajustement pendant l'utilisation peut être nécessaire pour soulager toute douleur.

Cette séquence de réglage donnera un confort de transport optimal.

Pour échanger facilement entre les utilisateurs, desserrez les sangles stabilisatrices supérieures et les bretelles d'épaule, puis ajustez la hauteur de la sangle d'épaule comme décrit ci-dessus. Utilisez les marques sur l'étiquette derrière le tampon lombaire comme guide. Remettez le support, puis retendez les sangles du stabilisateur supérieur et les bretelles d'épaule.

-Le dernier réglage est la sangle du sternum (Fig 1) serrez la boucle ensemble et ajustez la hauteur de la sangle du sternum en glissant des deux côtés vers le haut ou vers le bas.

-Les boucles coulissantes qui fixent la sangle du sternum aux bretelles ont une fente en elles. Cela permet de les enlever et de les repositionner dans la partie supérieure ou inférieure de la sangle de glissement pour convenir à l'utilisateur. La sangle du sternum est correctement positionnée lorsque la sangle croise votre poitrine juste en dessous de vos clavicules.

-Remarque: un ajustement pendant l'utilisation peut être nécessaire pour soulager toute douleur.

Cette séquence de réglage donnera un confort de transport optimal.

Passen Sie das Carry System an

Réglage du harnais de l'enfant

Le siège et le harnais pour enfants doivent être ajustés au fur et à mesure que votre enfant grandit ou si un autre enfant utilise un transporteur.


-Le siège réglable en hauteur permet à l'enfant de toujours s'asseoir dans la position idéale: le menton au niveau de la moitié supérieure du menton.

-Commencez par ajuster la hauteur du siège. Relâchez les sangles latérales du siège (Fig ⑤). Ajoutez la hauteur du siège à l'aide de la sangle de réglage de la hauteur du siège (Fig ⑥). Placez la sangle à travers la boucle de réglage pour soulever le siège. Pour abaisser le siège, retirez le bord de la boucle de réglage de la sangle pour la desserrer. Pour les enfants plus jeunes, la selle est réglée à la bonne hauteur lorsque votre enfant repose contre l'appuie-tête.

- Deux pédales pour enfants sous le support arrière
Certains parents se plaignent souvent que les enfants sont ennuyeux à marcher sur les pédales. Mais il y a aussi des parents qui pensent que l'utilisation des pédales peut rendre leurs enfants plus confortables. Lors de l'utilisation de la pédale, les parents doivent placer les pieds de l'enfant dans la pédale avec leurs mains.
De cette façon, les parents peuvent choisir d'utiliser ou non les pédales en fonction de leurs besoins.



Das Gurtzeug auf dem Creeper-Kinderträger ist leicht darauf eingestellt, für verschiedene Benutzer geeignet zu sein.
Die Haupteinstellung ist die Rückenlänge.



-Une fois le réglage de la hauteur du siège enfant terminé, ajustez l'élasticité de la bandoulière de l'enfant (Figure ⑦). L'élasticité de la sangle d'épaule est ajustée par un fermoir deux-en-un à l'extrémité avant du coussin de siège. Il y a deux inserts sur le fermoir. Ajustez la sangle sur l'insert pour atteindre le réglage de l'élasticité de la bandoulière de l'enfant.

-Le siège réglable en hauteur permet à l'enfant de toujours s'asseoir dans la position idéale: le menton au niveau de la moitié supérieure du menton.

-Serrez les sangles d'épaule au niveau des boucles latérales à déclenchement rapide. La ceinture-baudrier doit être serrée pour assurer un ajustement sûr.

-Le dernier réglage est les sangles latérales du siège (Fig ①). Placez-les pour ajuster la position des ailettes latérales rembourrées. Les bras de votre enfant doivent être à l'intérieur des nageoires.

Instructions d'entretien

-Les coussins rembourrés et l'appuie-tête sont tous amovibles pour le lavage.

-Nettoyez à l'eau chaude avec un détergent doux. N'utilisez pas d'eau de Javel.

-Assurez-vous que les coussins sont complètement secs avant de stocker le support arrière.

-Car le mélange peut se développer. Nous recommandons que les tampons soient placés dans un sac de lavage de protection si vous allez dans une machine car les patchs Velcro peuvent endommager d'autres vêtements.

调整运载系统

调整儿童背带

儿童座椅和安全带需要根据孩子的身高而进行调整。

-调整座椅高度可以让您的孩子始终坐在舒适的位置：孩子的下巴应该与口水垫的顶端齐平。

-从调整座椅高度开始。

松开座椅侧织带(图 ⑤)。

使用座椅高度调整织带调整座椅高度(图 ⑤)。

将织带穿过调节卡扣向上拉起以提升座椅。要降低座椅，请将调节卡扣的边缘从织带上拉出以松开座椅。

对于年龄较小的儿童，当您的孩子靠在头枕上时，座椅的高度为正确高度。

-背架下面的两只儿童脚踏板

一些家长经常抱怨儿童踩脚踏板很烦人。但也有一些家长也认为使用踏板可以让您的孩子更舒服。

在使用脚踏板时，家长需要用手将儿童的脚放入脚踏板中。

通过这种方式，家长可以根据自己的需求选择是否使用脚踏板。



CREEPER儿童背架上的成人肩带很容易调整，适应不同的用户，主要的调整部位是背部长度。

-展开后腰中部衬垫，衬垫底部与背架相连，用魔术贴和衬垫上的插片与背架固定（图 ①）。

-要缩短肩带长度请拉紧织带A；若要增加肩带长度请松开织带A并让肩带到合适的位置后拉紧织带并将衬垫放回原来位置。肩带的长短应该根据背负者身高进行调节。A织带左侧有身高尺码标。

-合适的位置：为了确保重量集中在后髋骨上，可以降低或提高肩带。

-松开顶部稳定带（图 ②）和肩带，然后将背带放在背上。系好臀部安全带，安全带顶部放在髋骨顶部。拉紧臀部安全带使其在臀部非常舒适，确保重量集中在后髋骨上，这一点非常重要。

-现在检查肩带的位置。你的肩膀顶部应该比肩带弯曲远离背带背板的地方高5厘米（图 ②）。

-注意：在第一次使用背架时，打开腰部衬垫可能更容易进行此调整。

-将肩带调整到一个用户后，在印刷标签上标记扣件的位置（图 ①）。通过标记每个用户的扣件位置，可以快速重新调整背带以适合每个人。

-现在通过拉紧臀部安全带开始最后的调整。它应该收紧，这样它在你的臀部非常舒适，不会四处移动。

-注意：如果不够紧，过多的重量会转移到肩上。如果太紧，你的血液循环可能会受到影响或你的髋骨感到不舒服。

-打开后面的储物仓，在背架的折叠处，将折叠的铰链压平。

-检查并调整臀部安全带，直到支架在你的臀部感觉稳定为止。

-一旦调整了臀部安全带，就可以拉紧肩带；站直，系紧肩带。

-肩带应该是舒适的，并承担一些负荷。


-注意：如果它们太紧，背负者会感觉不舒服。如果它们太松，载体就不会靠在你的背上。

-调整好肩带后，移动肩带顶部的滑动扣（图 ②）直到它们位于肩膀顶部。

-储物仓中的保温袋的体积约为2升，是由保温铝膜制成的，有保温效果。可以放置婴儿奶瓶等需要保温的饮食。

-最后一次调整是胸带（图 ①）。

将扣子扣在一起，通过上下滑动来调整胸带的高度。



将胸带连接到肩带上的滑动扣上有一个开口。这使得它们便于移除和安装，胸带的正确位置在锁骨下方的胸部。

注意：使用时可能需要调整，以缓解任何疼痛。

这种调整顺序将提供最佳的携带舒适性。

如果要改变使用者，请松开顶部稳定器背带和肩带，然后如上所述调整肩带高度。

使用腰垫后面标签上的标记为您的合适高度定位，以便您下次快速调整到合适位置。

将背带重新背上，然后重新拉紧顶部稳定器背带和肩带以适应需要。

对于年龄较小的儿童，当您的孩子靠在头枕上时，座椅的高度为正确高度。

-背架下面的两只儿童脚踏板

一些家长经常抱怨儿童踩脚踏板很烦人。但也有一些家长也认为使用踏板可以让您的孩子更舒服。

在使用脚踏板时，家长需要用手将儿童的脚放入脚踏板中。

通过这种方式，家长可以根据自己的需求选择是否使用脚踏板。



儿童座椅高度调整完成后，调整儿童肩带的松紧度（图 ①）。肩带的松紧度是通过座垫前端一只二插扣件进行调节的。扣件上有两只插件。调节插件上的织带以达到儿童肩带松紧度调节。

-如果胸带太低和太松，背带可能会从他们的肩膀上掉下来，你的孩子可能会爬出安全带，如果背带设置得太高太紧，可能会给孩子带来一些不适。

-注意：如果不够紧，过多的重量会转移到肩上。如果太紧，你的血液循环可能会受到影响或你的髋骨感到不舒服。

-注意：如果它们太紧，背负者会感觉不舒服。如果它们太松，载体就不会靠在你的背上。

-高度可调的座椅可以让孩子始终坐在理想的位置：儿童下巴与口水垫上端保持水平。

-肩带应该是舒适的，并承担一些负荷。

-注意：如果它们太紧，背负者会感觉不舒服。如果它们太松，载体就不会靠在你的背上。

-最后一次调整是胸带（图 ①）。

将扣子扣在一起，通过上下滑动来调整胸带的高度。

-储物仓中的保温袋的体积约为2升，是由保温铝膜制成的，有保温效果。可以放置婴儿奶瓶等需要保温的饮食。

护理说明

-垫子和头枕都是可以拆卸清洗。

-用温和的洗涤剂在温水中清洗，请勿使用漂白剂。

-确保垫子完全干燥后再存放托架，以免霉菌滋生。

我们建议将含有魔术贴片的部件放在洗衣机内的保护性洗衣袋中，因为魔术贴片可能会损坏其他衣服。