

# CHILD CARRIER INSTRUCTIONS



## IMPORTANT! READ CAREFULLY AND KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

This product complies with standard:EN 13209-1:2022 AND ASTM F2549-22  
Manufacturer: WIPHA importers  
Manufacturer's Address: 333 canal St, New Orleans, LA70130, United States.  
18 Rue des Bas Rogers, 92800, Puteaux, France.  
Location of Production: Nanjing City, Jiangsu Province, China P.C.: 210000.  
Phone: 0086 25 84643040 Production date: May 2023  
www.wipha.com

## WARNING

### FALL HAZARD


Your child can slip through leg opening or fall out of product and suffer a serious head injury.

- Always use child retention system and adjust to fit snugly.
- Do not use carrier with a child weighing less than 16lb(7.3kg) or more than 40lb(18kg).
- Do not load more than maximum overall weight:42lb(19kg) (Child+Cargo).
- Do not use carrier if child cannot sit upright unassisted.
- Do not place carrier on counter tops,or other elevated surfaces.
- Read all instructions before assembling and using the frame child carrier.
- Keep instructions for future use.
- Check to assure all buckles, snaps, straps, and adjustments are secure before each use.
- Never leave the child unattended in the carrier.
- Periodically check that the child's legs have adequate circulation.
- Be aware of fatigue during prolonged use. Take frequent breaks as needed.
- Never bend at waist; bend at knees.
- Items attached to the carrier may change the balance of the product and cause a hazardous, unstable condition.
- This carrier is designed only for use while walking. It should not be used for any sporting activities such as climbing, cycling, skiing, or similar activities.
- Never use a frame carrier when balance or mobility is impaired because of exercise, drowsiness, or medical conditions.
- Do not use this product near fire or open flame.
- Care should be taken to avoid hazards in the environment when in use, as the child may sit higher than the height of the caregiver. For example, door frames, low branches of trees, etc.
- Extreme hot or cold temperatures, including long exposure to the sun can cause exposed metal items to burn a child. Make sure there are no exposed metal items near the child when using the carrier.
- The statement that additional or replacement parts should only be obtained from the manufacturer, importer or organization responsible for its sale.
- The movements of you and your child may affect your balance when using this product, be careful when you bend over, lean forward, or lean sideways.

## ATTENTION

When using the carrier, the adult shall be aware of the following:

1. This frame carrier is designed for only one child to be carried by an adult.
2. Check the child carrier to assure all buckles, snaps, straps and adjustments are secure before each use. For all buckles, be sure that you hear an audible click when connecting and pull on buckle to confirm that a secure connection has been made.
3. Always inspect the child carrier prior to use for damage. Never use the child carrier with a bent frame. Never use with broken buckles anywhere on the pack. Never use with tearing, torn or ripped seams or fabric anywhere on the pack.
4. The carrier is suitable for leisure activities, but not for sport activities; e.g., skiing, cycling, etc.
5. Be careful when putting on or removing the children's bracket.
6. The adult's balance may be adversely affected due to movement of the child and also the adult.
7. The adult will need to take great care when bending/leaning sideways or forward.
8. Be aware that the child in the child carrier may suffer from the effects of weather and temperature before you do. Dress the child appropriately and occasionally check the temperature of their ears and face.
9. For sun protection, deploy the sunshade and for additional protection, apply sunscreen to child.
10. The child in the child carrier can become tired. Take frequent breaks when using your carrier.
11. Be careful to protect the child's feet when the child carrier is on or near the floor in order to avoid injury.
12. Do not let the child stand on the child seat within the carrier.
13. If the carrier becomes damaged, do not attempt to repair it yourself. The additional or replacement parts should only be obtained from the manufacturer, importer or organization responsible for its sale;
14. Failure to follow instructions may result in serious injury, permanent physical injury, or even death.
15. After each trip, please take the goods out of the storage bag. Removable pillows and saliva pads, hand wash with mild detergent or soap in warm water, and then hang them up to dry. Before storage, the carrier should be dry. Please store it in a dry place and avoid direct sunlight.



Do not tumble dry



Do not iron



Do not bleach

## FEATURES

-Inside the left-hand pocket is a pull-out mesh bottle pocket with shock card bottle retainer.

-Inside the main compartment there is a pocket, the volume of about 2 liters. The pocket has heat preservation effect. A separator is attached in the pocket.

-Reflective webbing light loop Self-contained sunshade.  
Size:350\*270\*700 Weight:2.6KG

-Your Creeper child carrier is designed to safely and comfortably carry a child that can hold their head up independently and is not more than 100cm tall. Do not use carrier with a child weighing less than 16 lb or more than 40 lb.

-The harness and the child's seat and harness need to be adjusted to suit each user to ensure safe and comfortable use.

### LOADING AND LIFTING THE CARRIER

**Never leave a child in the carrier unattended as the carrier could fall over if on uneven ground or if the child moves.**

-Always load your child with the carrier on flat level ground or on a floor. There are two webbing loops on the back side of the carrier. This webbing loop can be used both as a handle and as a pedel. They are designed for this purpose.

-Either loosen the shoulder straps, or unclip one or both of the quick-release shoulder strap buckles. Lift your child into the carrier. Once your child is seated into the carrier, clip the chest buckle together and tighten the webbing as described earlier. Re-attach and tighten the shoulder straps snugly.

-Never leave a child in the carrier unrestrained. Once the child is secure adjust the padded side fin straps so the child is as possible to the back of the wearers harness. This will bring the load closer to your back making the loaded carrier more stable on your back and easier to carry.

-Once the child is loaded and secure and the side straps adjusted lift the carrier onto your back. This can be initially difficult. There are several ways to make it easier: you can lift the loaded carrier onto a higher surface such as bench, table or chair and then turn around and put the carrier onto your back. Another option is to crouch beside the carrier and with one knee on the ground lift the loaded carrier onto your other knee.

-Pivot your torso to get one shoulder(same side as the knee that has the carrier on it) under the shoulder strap. Lean forward so the carrier is on your back and put your other arm under the other shoulder strap. You can now stand and secure the hip belt. If there is someone to help you, the front and rear carry handles can be used to lift the carrier up to a comfortable height with the child sitting in place.

-We do not recommend that you lift the loaded carrier by only one handle to put it on your back. It may not be stable enough. When the child is in the carrier, only lift it using both handles together.

## ADJUST THE CARRY SYSTEM

### INSTRUCTIONS FOR SAFE ASSEMBLY

WIPHA child carriers come fully assembled. Before placing child in carrier, always deploy the kickstand until it is fully opened and audio feedback confirms it is locked in place. For shipping purposes, the side wings are folded inside the carrier. Tighten the side compression straps on rear wings before use.



**WARNING**  
Always ensure the kickstand is fully deployed before carrier is placed on the ground.

### MAINTENANCE

Regularly inspect your child carrier for damage and signs of wear. For repairs or questions, please contact your local dealer or visit our website for customer service information: www.wipha.com

### MAINTENANCE RECOMMENDATIONS

>Store in a dry area out of direct sunlight.  
>Wash the carrier if it comes in contact with mud, sand, salt, etc.  
>Remove contents from carrier after each trip.  
>Before storing, your carrier should be dry to prevent the growth of mold or bacteria.  
>The carrier, including the removable drool pad should be hand washed with a mild detergent in warm water, then hung to dry. Never use harsh cleansers or solvents.

### HOW TO FIT TO AN ADULT

The WIPHA carriers have a wide range of adjustability to fit many different body types.

TORSO ADJUSTMENT		
XS	<37CM	<15"
S	37-41CM	15-16"
M	41-46CM	16-18"
L	46-50CM	18-20"
XL	>50CM	>20"

### ADJUSTABLE HIPBELT

Adjust the HIPBELT to ensure that the main weight of the carrier is supported by your hips. Bear key point: back waist above hip. This adjustment step is very important. To adjust:  
A Separate the hook and loop between the hip belt pocket and the hipbelt padding and move the hipbelt pad forward or backwards as needed. Once adjusted, reconnect the hook and loop.  
Proper fit ensures that the padding fully wraps around your Hipbones.



Bearkey point: backwaist above hip

# Ajuster le système de portage

B.Finally tighten this webbing to make the back frame closer to your torso.  
Proper fit-With the hip belt positioned directly over your hip bones.the top of the shoulder pad should sit just below the base of your neck.



Finally tighten this webbing to make the back frame closer to your torso.

## TORSO ADJUSTMENT

The carrier has 15 cm/6 in of adjust ability, fitting torsos from 38-56cm/15-22 in.

To adjust:  
A.There is a shoulder strap length adjustment fastener under the breathable mesh on the back. Adjust the length of the shoulder straps through this fastener to suit torso of different heights.



Use this fastener to adjust the length of the shoulder straps to suit different bodies.

## HOW TO ADJUST THE CHILD HARNESS

### ADJUST CHILD'S HEIGHT

A.Pull up on the webbing connected to the side squeeze buckle to raise the seat. To lower, grab the top of the side squeeze buckle, pull toward the rear of the carrier and push the child seat downward.

Proper fit-The child's chin should be level with the top of the drool pad.



The height of the seat cushion can be adjusted by adjusting this fastener.

### ADJUST CHILD'S SHOULDER HARNESS

A.Use this fastener to adjust the shoulder straps on the child's shoulders to just fit on the child's shoulders.  
B.The appropriate length of the shoulder strap concerns the safety and comfort of the child.  
Proper fit-The shoulder harness should be tight but still comfortable against the child's shoulders, chest and stomach.



Adjust the tightness of the child's shoulderstrap through this fastener.

### ADJUST LEG LOOPS


A. Fasten the side squeeze buckles on both sides of the child carrier and tighten the webbing.  
Proper fit-The leg loops should be tight but still comfortable against the child's legs.



Adjust this fastener so that the leg ringfits comfortably on the child's leg.

### Instructions pour un assemblage sûr

Les porte-enfants WIPHA sont entièrement assemblés, avant de placer l'enfant dans le porte-bébé, déployez toujours la bêquille jusqu'à ce qu'elle soit complètement ouverte et que le retour audio confirme qu'il est verrouillé en place, à des fins d'expédition, les ailes latérales sont repliées à l'intérieur du transporteur. Serrer les sangles de compression latérales sur les ailes arrière avant utilisation.



#### Attention

Assurez-vous toujours que la bêquille est entièrement déployée avant que le porte-bagages ne soit placé au sol.

### Maintenance

Inspectez régulièrement votre porte-enfant à la recherche de dommages et de signes d'usure. Pour des réparations ou des questions, veuillez contacter votre concessionnaire local ou visitez notre site Web pour obtenir des informations sur le service à la clientèle: [www.wipha.com](http://www.wipha.com)

### Recommandations relatives à l'entretien

>Conserver dans une zone sèche à l'abri de la lumière directe du soleil.  
>Lavez le support s'il entre en contact avec de la boue, du sable, du sel, etc.  
>Retirez le contenu du transporteur après chaque voyage.  
>Avant de stocker, votre porteur doit être sec pour empêcher la croissance de moisissures ou de bactéries.  
>Le support, y compris le tampon de bave amovible doit être lavé à la main avec un détergent doux dans de l'eau tiède, puis accroché à sécher. N'utilisez jamais de nettoyants ou de solvants durs.

### Comment s'adapter à un adulte

Les transporteurs WIPHA ont un large éventail d'adaptabilité à de nombreux types de corps différents.

Ajustement du torse		
XS	<37CM	<15"
S	37-41CM	15-16"
M	41-46CM	16-18"
L	46-50CM	18-20"
XL	>50CM	>20"

### HIPBELT réglable

Ajustez le HIPBELT pour vous assurer que le poids principal du transporteur est supporté par vos hanches. Point clé de l'ours: la taille arrière au-dessus de la hanche. Cette étape d'ajustement est très importante. To adjust:  
Séparez le crochet et la boucle entre la poche de la ceinture de la hanche et le rembourrage de la ceinture et déplacez le coussin de la ceinture vers l'avant ou vers l'arrière au besoin. Une fois ajusté, reconnectez le crochet et la boucle. Ajustez correctement-assurez-vous que le rembourrage s'enroule complètement autour de votre Hipbones.



Bearkey Point: le dos au-dessus de la hanche.

B. Enfin serrer cette sangle pour rendre le cadre arrière plus proche de votre torse. Bon ajustement-la ceinture de la hanche positionnée directement au-dessus de vos os de la hanche. Le dessus de l'épaule devrait s'asseoir juste en dessous de la base de votre cou.



Enfin serrer cette sangle pour faire. Le cadre arrière près de votre torse.

### Ajustement du torse

Le transporteur a 15 cm / 6 dans la capacité d'ajustement, ajustant les torses de 38-56cm / 15-22 in.Pour ajuster:  
R. il y a une attache de réglage de la longueur de la sangle d'épaule sous la maille respirante sur le dos. Réglez la longueur des sangles d'épaule à travers cette attache pour convenir au torse de différentes hauteurs.



Utilisez cette attache pour ajuster la longueur des sangles d'épaule en fonction de différents corps.

### HOW TO ADJUST THE CHILD HARNESS

#### Ajuster la taille de l'enfant

A. Pull up sur la sangle reliée à la boucle latérale serrer la boucle pour soulever le siège. Pour descendre, saisissez le haut de la boucle latérale, tirez vers l'arrière de la porteuse et poussez le siège enfant vers le bas.  
Bon ajustement-le menton de l'enfant doit être au niveau du dessus du tampon de bave.



La hauteur du coussin du siège peut être ajustée en ajustant cette fixation.

### Ajuster la ceinture-baudrier de l'enfant

A. utilisez cette attache pour ajuster les sangles d'épaule sur les épaules de l'enfant pour l'adapter aux épaules de l'enfant.  
B. la longueur appropriée de la sangle d'épaule concerne la sécurité et le confort de l'enfant.  
Ajustement approprié-le harnais d'épaule doit être serré, mais toujours à l'aise contre les épaules, la poitrine et l'estomac de l'enfant.



Réglez l'étanchéité de la sangle d'épaule de l'enfant à travers cette attache.



Français 8

### Ajuster les boucles LEG

A. fixer les boucles latérales serrées des deux côtés du porte-enfant et serrer la sangle.  
Ajustement approprié-les boucles des jambes doivent être serrées mais toujours à l'aise contre les jambes de l'enfant.



Ajustez ce fasterer afin que l'anneau de la jambe s'adapte confortablement sur la jambe de l'enfant.

### Serrer les ailes latérales

A. pincer le côté de l'accès latéral serrer la boucle sur le support de l'enfant et serrer la sangle des deux côtés.  
Réglage approprié-les ailes latérales doivent être fermées de manière à ce que les deux ailes se chevauchent et que l'enfant soit bien assis dans le siège.



Stockage des sacs d'hydratation et sortie de tuyau.



hydration bag storage and hose outlet

### Opération SUNSHADE

A. insérez le tube du support de pare-soleil des deux côtés du haut du support.  
B. Fix la boucle d'olive sur l'anneau de corde de la glissière de sécurité des deux côtés du cadre arrière.



Français 9